

Einrichten von SNOM Telefon beOnline voice



SNOM

BESCHREIBUNG

Snom ist ein Hersteller von VoIP Telefonen, Snom Telefone sind mit unserer VoIP Plattform getestet und bieten viele Funktionen und einfache Konfiguration.

Die Verschiedenen SNOM Telefone finden Sie auf der Hersteller Website.

<http://www.snom.com/de/startseite/>

EINRICHTUNG

1. Verbinden Sie über das Webinterface auf Ihr SNOM
2. Geben Sie Ihre VoIP Zugangsdaten ein

Identity active	ON
Displayname	Ihre Telefonnummer
Account	Ihre Telefonnummer
Password	Ihr SIP Passwort
Registrar	sip.beonline.nexphone.ch
Outbound Proxy	sip.beonline.nexphone.ch
Authentication Username	Accountnummer (xxxxxxxxxxx.xxxx)

Operation

- Home
- Directory

Setup

- Preferences
- Speed Dial
- Function Keys
- Identity 1**
- Identity 2
- Identity 3
- Identity 4
- Identity 5
- Identity 6
- Identity 7
- Identity 8
- Identity 9
- Identity 10
- Identity 11
- Identity 12
- Action URL Settings
- Advanced
- Certificates
- Software Update

Status

- System Information
- Log

Login
SIP
NAT
RTP

Login Information:

Identity active: on off ?

Displayname: ?

Account: ?

Password: ?

Registrar: ?

Outbound Proxy: ?

Failover Identity: None ?

Authentication Username: ?

Mailbox: ?

Ringtone: Ringer 1 ?

Custom Melody URL: ?

Display text for idle screen: ?

XML Idle Screen URL: ?

Ring After Delay (sec): ?

Record Missed Calls: on off ?

Record Dialed Calls: on off ?

Record Received Calls: on off ?

Identity is hidden: on off ?

Apply Re-Register Play Ringer

Remove Identity Remove All Identities

3. Klicken Sie Apply